
NEBULA QUICK OPERATION

Press the Back key to reach the top menu—the LCD shows “**Theatrelight NZ**”. Softkeys are shown in italics eg: “*setup*”.

SETTING DMX START ADDRESS AND LOCKING THE KEYS

If the Nebula is set to DMX Start mode, the current Start channel shows on the top menu page. To change the start address:

1. From the top menu, press **Menu** three times to arrive at the DMX Start Address menu.
2. Press **Up** ▲ or **Down** ▼ to adjust the DMX address. Press **Left** ◀ or **Right** ▶ to adjust tens and hundreds.
3. Press **Back** to return to the top menu: the screen shows “Changes saved to flash memory”.
4. To lock the keypad, hold ◀ + ▶ + ▲ for 2 seconds. To unlock the keypad, hold ◀ + ▶ + ▼ for 8 seconds.

SETTING DMX FAIL MODE

To set the DMX Fail Mode to either “Fade to Black” or “Hold DMX levels” :

1. While in the DMX Start Address Menu above, press “*fail*” (Menu) to enter the DMX Fail mode menu.
2. Use the arrow keys ▲ / ▼ to select the mode, then press “*on*” (▶) to set the mode On.
3. Press “*times*” (Menu) to enter the DMX Fade Delay/Time menu: use the arrow keys to edit the times.
4. Press **Back** to return to the top menu: the screen shows “Changes saved to flash memory”.

SETTING DIMMER PARAMETERS

To set Test, Min, Max, Non-Dim, Off levels, Curve, Proportional levels, or Softstart time for each dimmer:

1. From the top menu, press **Menu** twice, select “Dimmer Settings”, press “*setup*” (Menu).
2. Use the arrow keys to select the parameter to adjust, then press “*setup*” (Menu).
3. Use the arrow keys to select the dimmer and adjust parameters, with softkeys “*flash*” and “*all*”.
4. Press **Back** to return to the top menu: the screen shows “Changes saved to flash memory”.

RESETTING ALL NEBULA PARAMETERS

To reset all Nebula parameters:

1. From the top menu, press **Menu** twice, select “Dimmer Settings”, press “*setup*” (Menu).
2. Use the arrow keys to select “Reset Commands” (line 9), press “*setup*” (Menu).
3. Select “Reset Dimmers + DMX”, press “*select*” (Menu), press “*OK*” (Menu).
4. The screen shows “Resetting all Dimmer and DMX parameters”, then resets to the top menu.

NEBULA TABLE OF CONTENTS

NEBULA INTRODUCTION	1	Setting non-dim levels	16
FRONT PANEL LEGEND	2	Setting off levels	16
NEBULA OVERVIEW	3	Setting dimmer curves	16
LCD display	3	Setting proportional levels	17
Keys	3	Setting soft-start times	17
LEDs	3	Resetting DMX and dimmer parameters	17
Cooling	4	Displaying input DMX levels	17
Power supply	4	Displaying final dimmer levels	18
DMX control	4	Displaying temperature history	18
Remote control	5	Displaying voltage and frequency	18
Dimmer parameters	5	Calibrating voltage	18
Dimmer settings priority	8	Displaying fan status	18
Levels display	9	Testing the fan	19
Resetting Nebula default parameters	9	Displaying scenes playback levels	19
NEBULA PARAMETERS.....	10	Displaying remote control data	19
DIMMER INSTALLATION.....	12	NEBULA STAGE SCENES OPERATION	20
Supply transformer	12	Setting local scenes on/off	21
Dimmer supply cabling	12	Setting remote scenes on/off	21
Dimmer load cabling	12	Setting up area ID and report ID	21
DMX-512 installation	13	setting scenes levels	21
NEBULA DIMMER OPERATION	14	Setting scenes labels	22
Unlocking the keys	14	setting scenes fade times	22
Locking the keys	14	Playing back scenes	23
Setting DMX start or patch mode	14	Copying and pasting scenes	23
Setting DMX start or patch addresses	14	NEBULA STAGE SHOWS OPERATION	24
Setting DMX fail mode	14	Setting local shows on/off	25
Setting DMX fail mode times	15	Setting remote shows on/off	25
Setting DMX fail scene	15	Setting up area ID and report ID	25
Setting dimmer test/set levels	15	Playing back or pausing the current show	25
Setting dimmer minimum levels	15	Changing the current show number	26
Setting dimmer maximum levels	16	Changing the current show cue	26

Editing the current show cue	27
Setting show start and end scenes	27
Setting show titles	28
Setting show or chase type	28
REMOTE SCENE AND SHOW CONTROL.....	30
Communication	30
RS-485 transceiver	30
Power supply	30
Connection and wiring	30

Theatrelight Wallplates	31
Wallplate electronics	31
Remote controlled scenes	31
Remote controlled shows	32
MAINTENANCE	33
SPECIFICATIONS.....	34
DIMENSIONS.....	36
GLOSSARY OF THEATRE LIGHTING TERMS	37
INDEX.....	39

NEBULA INTRODUCTION


The Theatrelight Nebula is a general purpose 19 inch rack-mounting dimmer pack for use in TV Studios, Theatres, Concert halls, or any venue requiring an intelligent and reliable dimmer installation. The Nebula design supersedes the original Theatrelight Digital Dimmer. The new design uses the latest microprocessor and components chosen for reliability and long MTBF (Mean Time Before Failure). The isolated DMX input presents only 1/10th standard loading, reducing the possibility of DMX errors. Additionally, zero-crossover noise filters ensure correct triggering and immunity to mains interference even in the most adverse environment. The wide input voltage and frequency range afforded by Theatrelight's in-house designed switch-mode power supply allows the Nebula to work on any voltage from 90 volts AC to 265 Volts AC, and on any frequency from 45 to 65 Hertz, making it suitable for use in any country. The Nebula is also fitted with an RS485 communication system for use with other Nebulas, with remote keyplate lighting controllers, or as a control, reporting, and monitoring gateway. The Nebula is available in a number of versions: 12, 6, and 3 channel models, using SCR, IGBT, or Sinewave dimming methods. A number of different mains input and output terminations are available, and special socket versions can be made to customer order.

The Nebula software is available in a number of different software configurations according to application. A similar control system and software is also used in the following Theatrelight products: **Meteor-** a wall mounting Stage or Environmental dimmer, and **Quasar-** a 2u high rack-mounting Environmental dimmer pack for smaller installations.

NEBULA FEATURES

- Simple and easy to use menu system with large 4 line, 20 character auto dimming LCD display
- Each dimmer channel may be patched to any DMX address (including all on the same DMX address)
- Individual Minimum, Maximum, Off, Proportional, and Test level per dimmer
- Individual Soft-start Time and Dimmer Curve (including Non-Dim) setting per dimmer.
- All dimmer parameters held in non-volatile flash memory
- Temperature controlled, variable speed cooling fan for low acoustic noise and long life
- Protection by Thermal/Magnetic circuit breakers
- High immunity to mains interference and low DMX signal
- Isolated, floating DMX input, 1/10th standard RS-485 load
- Isolated, floating RS-485 control for reporting and building control applications, 1/10th standard RS-485 load

FRONT PANEL LEGEND



- A:** Thermal/Magnetic Circuit Breakers (MCBs) protect each dimmer in the event of a lamp failure or load short circuit.
- B:** 4 row x 20 character Blue LCD display with white LED backlight, with large clear characters for easy readability.
- C:** The DMX LED shows the presence of DMX signal, and any errors. The TEMP LED shows the internal temperature, while the Remote LED indicates the remote keypads are active (with appropriate software).
- D:** Simple keyboard and easy to understand menu system allow quick setup of all Nebula functions and parameters.
- E:** A B C LEDs indicate presence of mains power on each phase

NEBULA OVERVIEW

The following description provides an overview of the capabilities of the Nebula.

LCD DISPLAY

The 4 line, 20 character per line Blue LCD display has white LED backlighting, giving excellent contrast and readability under all lighting conditions. The brightness of the display goes to full at the first key press, and reduces after 10 minutes

KEYS

The Nebula is operated by a small keypad of 6 keys. The key operation is designed to be simple and to allow the operator fast and easy access to all dimmer functions. The Menu key steps down through the menu tree, while the Back key steps back. The keys Up ▲, Down ▼, Left ◀, and Right ▶ are used for navigation, and to adjust values. In most menus the function of the key is indicated in the bottom line of the LCD (“softkey”), making for easy understanding. If a value is changed (such as the DMX Start Address), the new value will be saved automatically to flash memory after a timeout period of 10 minutes. Alternatively the new value can be saved immediately by pressing the Back key to return to the top menu. The keys may also be locked to prevent unauthorised operation.

LEDS

Front panel LEDs are provided for display of DMX signal, over-temperature indication, remote key operation, and proper mains presence on Phases A B and C. All LEDs are initially turned on at power up, before assuming their correct status.

DMX LED

The Green DMX LED is on continually On if DMX is enabled and the DMX signal is good. The LED flashes regularly if DMX is enabled but the DMX signal is disconnected. The DMX LED switches off or flashes irregularly if the DMX signal has errors, or if the DMX signal is wrongly phased. Disabling DMX sets the DMX LED off regardless of the state of the DMX signal.

Remote LED

The Amber Remote LED indicates that the Remote control keypads (available in Stage or Environ software models) are activated.

Phase A B C LEDs

Green LEDs A B C indicate presence of mains power on each phase.

4 NEBULA OPERATION

Temperature LED

The Red temperature LED is normally off. In the event that the internal temperature of the Nebula reaches 50 degrees Centigrade, the LED starts blinking. The LED turns on fully when the temperature reaches 60 degrees. If the internal temperature reaches 70 degrees the Nebula forces a fade out over 7 seconds of all dimmer levels. The levels are faded in again over 7 seconds when the temperature drops below 70 degrees.

COOLING

The Nebula is cooled by a long life, low voltage, speed controlled fan. Fan speed is proportional to temperature—the fan starts at half speed at 35 degrees Centigrade and increases to full speed at 45 degrees. The fan remains on for 10 minutes after load current has dropped to zero to prevent heat buildup in the case.

Air is blown into the Nebula case from the left side, and the warmed air exhausted through slots in the front panel. This arrangement allows the operator to provide a cooled and filtered air supply under pressure into a rack cabinet so as to minimise the build-up of dust in the dimmer electronics. Nebula dimmers should be mounted in a position where acoustic noise generated by the packs cannot interfere with a performance.

POWER SUPPLY

The Nebula is designed to be supplied with power mains of 90 to 265 volts AC, 1, 2 or 3 phase and Neutral, 45 to 65 Hz. Do not use the Nebula on a 3 Phase Delta connection (ie with no Neutral wire). Each Nebula must be properly earthed.

DMX CONTROL

DMX-512 control is commonly used in Theatre and TV for lighting control. One DMX line or “Universe” addresses a maximum of 512 dimmers. Each Nebula may be set to either DMX Start Mode or DMX Patch mode:

DMX Start Mode

In DMX Start mode, the DMX Start Number for the pack may be set to any number between 1 and 4096. The start number means the DMX address which Dimmer 1 responds to. DMX addresses of the following dimmers are then set automatically: the address of Dimmer 2 is set to the DMX Start number plus 1, and so on. The DMX address number may be chosen to be any number between 1 and 4096 to ease the task of calculating dimmer numbers in multiple DMX universe systems—the Nebula automatically subtracts multiples of 512 from any number 513 and up.

DMX Patch Mode

In DMX Patch mode, every dimmer in the pack may be set to its own DMX address. Using this built in patch system allows great flexibility in matching dimmers to loads—if a large number of loads are required to be controlled together, any number of dimmers (including all dimmers in the pack) can be controlled by a single DMX channel. As with DMX Start Mode above, The

DMX address number may be chosen to be any number between 1 and 4096 to ease the task of calculating dimmer numbers in multiple DMX universe systems.

DMX Disable

DMX Start or Patch modes may be switched on or off. If both are off the Nebula then ignores all DMX control levels.

DMX Fail Modes

The Nebula provides two options in case the DMX signal fails, or the DMX signal is turned off, as for example when the control panel is turned off at the end of a show. The options are

Fade to blackout- after a delay time, the dimmer levels are faded to blackout. Both the delay time and the fade time are programmable from Instant to 30 minutes.

Hold last DMX levels- the last valid DMX levels are held until the next valid DMX input, or the pack is switched off

REMOTE CONTROL

The dimmers of the Nebula may also be controlled by RS-485 signal when fitted with the appropriate software. In this case the Remote LED indicates that the Nebula is set to respond to remote control from wall-plates or computer.

DIMMER PARAMETERS

The dimmer channels in the Nebula have a number of parameters which may be set individually for each dimmer. As incorrect setting of these parameters can prevent the Nebula from working as expected, care must be taken when setting them up.

Test and Set Dimmer levels

Normally each dimmer receives control from the DMX line or RS-485 control where fitted. However the Test/Set options allow each dimmer to be set to a level which overrides the input from these sources. This override level can be set to any level between Off and Full. An "All" function allows all Test/Set levels to be faded up or down at the same time. Each dimmer can also be flashed instantly to Full for identification. The "All" function may also be used with Flash, allowing all dimmers to be flashed to Full at the same time.

The Test functions are of use during set-up to help check lamps or wiring problems without the use of a control panel. The Set function is also useful where lights such as orchestra or working lights must be left on permanently.

Minimum and Maximum Dimmer levels

Each dimmer may be set to its own minimum level, and its own maximum level. The "All" function allows all minimum or all maximum levels to be set at the same time.

6 NEBULA OPERATION

The minimum setting can be used to keep lamp filaments warm for fast response time, or for example to maintain lighting at a minimum level of illumination, a requirement often needed by orchestra lighting and working lights.

The maximum setting can be used for example to prolong lamp life, which is very sensitive to over-voltage conditions. For this reason, the maximum setting has higher priority than the minimum setting.

As both Minimum and Maximum levels may be set to anywhere from Off to Full, care needs to be taken in setting these levels.

Dimmer curves

Each dimmer in the Nebula may be set to a number of dimmer curves. Curves fitted as standard are:

Incandescent: The Incandescent dimmer curve is suitable for most Theatre and TV applications using incandescent bulbs whether normal tungsten or tungsten halogen type. The curve is specially tailored to provide linear apparent light under these conditions.

Non-Dim: The Non-Dim curve selection is for use with loads which must be switched on and off, such as motors, smoke machines, and other effects. Each dimmer using the Non-Dim curve switches on at a user programmable Non-Dim level (see below): any control level at this level or above will switch the dimmer to Full instantly. Once On, the dimmer will stay on until the control level goes 5% below the Non-Dim level. An "All" function allows all Non-Dim switch levels to be set at the same time. The Non-Dim facility may be combined with the Minimum and Maximum settings to switch the dimmer output between any two selected output voltages.

Television: A modified Incandescent dimmer curve suitable for adjusting the colour temperature of incandescent bulbs in TV or Film studios. This curve is not intended to be used as a linear dimming curve.

Fluorescent: This curve is suited to dimming mains ballasted fluorescent lamps fitted with filament transformers and pulse ballasts. The flicker apparent at low dim levels can be controlled by setting the Off level (see below).

Neon: This curve is suited to dimming neon discharge tubes fitted with pulse ballasts. The flicker apparent at low dim levels can be controlled by setting the Off level (see below).

Linear Power: This dimmer curve outputs linear RMS power against DMX level for use when the Nebula is used to control heating elements in ovens etc.

Linear Phase Angle: This dimmer curve outputs linear phase angle against DMX level.

The "All" function allows all dimmer curves to be set at the same time. Each dimmer can also be flashed instantly to Full for identification. Other curves, or custom dimmer curves may be included by arrangement with Theatrelight.

Non-Dim levels

When the dimmer curve is set to Non-Dim as described above, the Non-Dim switching level may be programmed individually for each dimmer between the levels of 10 and 90%. The "All" function allows all levels to be set at the same time.

Off levels

For all dimmer curves, the Off Level may be programmed individually for each dimmer. If the control level is below this level, the dimmer is off; above this level the dimmer follows the normal selected dimmer curve. The "All" function allows all levels to be set at the same time. The Off Level is of most use in controlling unwanted flicker of Fluorescent and Neon tubes at low levels.

Proportional Dimmer levels

Each dimmer may be set to its own proportional level. The "All" function allows all levels to be set at the same time.

The proportional level acts as a master over the incoming dimmer control level. For example if the proportional level is set at 50%, the dimmer level will always be at half of the fader setting on the control panel. The proportion level setting may be used to balance light output of luminaires set to the same DMX address, which is useful in balancing cyclorama floodlights. The setting may also be used to proportionally control the maximum output from the dimmer for example where 110 volt Par cans are used on a 220-240 volt mains supply.

The proportional setting has a higher priority than the maximum setting. As the Proportional level may be set anywhere from Full to Zero, care needs to be taken in setting the level.

Softstart Fade Times

Each dimmer may be set to its own softstart fade time. The "All" function allows all softstart times to be set at the same time. A softstart fade up limits the inrush current into cold tungsten filament bulbs. This initial current may be as much as 12 times the normal working current of the filament: limiting this current greatly prolongs lamp life.

The softstart time for each dimmer can be set from 0 to 1 second in 100 millisecond steps. A shorter time gives a faster response; a longer time gives longer lamp life. For most stage lighting requirements, a time of 200 to 400 milliseconds (0.2 to 0.4 seconds) is suitable. Longer times (up to 1 second) should be applied to larger size bulbs as used in film and TV studios to prolong lamp life. The softstart time is applied after processing of Non-Dim switch levels. This allows limiting high starting currents during start-up of cap-start motors or other capacitive loads. If this facility is not required, then Non-Dim channels should have their softstart times set to zero. Note that an initial softstart time of 2 seconds is applied to all channels after the Nebula is powered on (excepting Non-Dim channels).

DIMMER SETTINGS PRIORITY

The dimmer settings described above are processed in a fixed priority. Levels are processed and passed to the dimmers in the following order of increasing priority:

1/ The DMX control level (or the Fail DMX control level) and the Scenes or Preset levels (if fitted) for that dimmer are mixed on an HTP (Highest Takes Precedence) basis.

2/ If the Test/Set level for the dimmer is set between Off and Full (or flashed), the Test/Set level replaces the dimmer level. If no Test level is set for that dimmer, no change is made. All Test/Set levels are disabled by the Reset command.

3/ If the control level is below the Off Level set for that dimmer, the control level is set zero. If the control level is above the Off Level, no change is made. All Off Levels are set zero by the Reset command.

4/ If the dimmer curve is set to Non-Dim, the control level will be switched to Full if over the Non-Dim level, and switched off if under. The Non-Dim level may be set anywhere between 10% and 90%. All Non-Dim levels are set zero by the Reset command.

5/ If the Minimum setting for the dimmer is set above 0%, the dimmer level cannot be lower than that level. If the Minimum setting is 0% for that dimmer, no change is made to the level. All Minimum levels are set zero by the Reset command.

6/ If the Maximum setting for the dimmer is set below 100%, the dimmer level cannot be higher than that level. If the Maximum setting is Full for that dimmer, no change is made. Giving Minimum and Maximum a higher priority than Non-Dim permits switching between any two voltages to suit the application. All Maximum levels are set Full by the Reset command.

Note that the normal Incandescent curve is used to define any Minimum or Maximum voltage limits imposed on dimmers selected to Non-Dim.

7/ If the Proportional Level for the dimmer is set lower than 100%, the control level for that dimmer is multiplied by the Proportional level. If the Proportional Level for the dimmer is set to 100% (F), no change is made. All Proportional levels are set to 100% (F) by the Reset command.

8/ Finally, the fade up rate of the resulting level is limited by the Softstart Time programmed for the dimmer channel. If the Softstart time is set to zero for that dimmer, no change is made to the fade up rate. The Softstart time applies only to the Up fade rate—it does not affect the Down fade rate of the control level applied to any dimmer. All Softstart times are set to 300msec by the Reset command.

9/ The phase On time for each dimmer is then calculated from the final dimmer level according to the Dimmer Curve programmed for that dimmer. All dimmer curves are set to Incandescent by the Reset command.

LEVELS DISPLAY

The LCD screen may be set to read out a number of operating conditions.

Input DMX levels

The LCD screen displays the latest input DMX levels before modification by any Test, Minimum or Maximum settings etc.

Final Dimmer levels

The LCD screen displays the final control level applied to the chosen dimmer curve for each dimmer. This level shows the level modified by the following settings: Test, Min, Max, Non-Dim, Off, Proportional, and softstart.

Temperature history

The LCD screen displays the following six readouts taken from a sensor in the exit air flow: the current temperature, the temperature 30 minutes ago, one hour ago, and two hours ago, the maximum temperature reached over the previous two hours, and the average temperature over the previous two hours. The timing is started from initial power on. Temperatures are in degrees Centigrade.

Voltage and Frequency

The LCD screen displays the RMS voltage on Phases A, B, and C, and the frequency in Hertz of each phase. Voltages are shown to the nearest volt, and frequency to the nearest 0.1 Hz. Each phase voltage may be individually calibrated against a known accurate RMS voltmeter. Calibration levels are held in Flash memory, and not affected by any reset command.

Fan Status

When set to this mode the LCD screen displays the Cooling Fan level This display also has a fan test-at-full function, and also shows the current temperature in degrees Centigrade.

Scenes Playback levels

When set to this mode the LCD screen displays the playback levels from Scene, Chases and Shows.

Fan Status

When set to this mode the LCD screen displays the latest commands over the Remote RS-485 line. The first 21 values are displayed in hexadecimal format. This display is of use in setting up wallplates and installing remote computer control of Nebula dimmers.

RESETTING NEBULA DEFAULT PARAMETERS

All Nebula parameters may be reset to default values. These default values are described in the next section.

NEBULA PARAMETERS

The range and values after Reset of the different parameters of the Nebula are described below. All parameters are held in permanent flash memory.

DMX START SETTINGS	Range	After Reset	Notes
DMX Start Mode	On/Off, 1-4096	On, 1	Addresses over 512 have n*512 subtracted
DMX PATCH SETTINGS	Range	After Reset	Notes
DMX Patch Mode	On/Off, 1-4096	Off, 1, 2, 3...	Addresses over 512 have n*512 subtracted
DMX FAIL MODES	Range	After Reset	Notes
Fade to Black	On/Off	On	Mutually exclusive with Hold mode
Fade to Black delay/fade times	Instant-30 minutes	5 mins/30 secs	
Hold Last Levels	On/Off	Off	Mutually exclusive with Fade mode
DIMMER SETTINGS	Range	After Reset	Notes
Test/Set Levels	Disabled, 0-100%	Disabled	
Minimum Levels	0-100%	0%	
Maximum Levels	0-100%	100%	
Non-Dim levels	10-90%	50%	Hysteresis = +0%, -5%
Off levels	0-90%	0%	Hysteresis = +0%, -1%
Dimmer curve	In,ND,TV,FI,Ne,LP,LA	In	In = Incandescent, ND = Non-Dim TV =TV/Film colour temp control, FI, Ne = Fluor/Neon discharge tubes, LP/LA = Linear Power/Linear Phase Angle
Proportional Levels	0-100%	100%	
Soft Start Times	0-1.0 second	300 msec	Up time only (Down time always instant)
KEY LOCK	Range	After Reset	Notes
Key Lock	On/Off	Off	Only accessible in Menu Level 0

SCENES SETTINGS	Range	After Reset	Notes
Local Scenes	On/Off	Off	If On, turns off Shows
Remote Scenes	On/Off	Off	If On, turns off Shows
Area ID	1-8	1	Sets scenes/shows area match
Report ID	1-250	1	For use with report software
Scenes number range	1-64	Scene 1	
Scenes labels	8 alpha-numeric digits	Look 1-64	Includes U/case, L/case, and symbols
Scenes dimmer levels	0-100%	0%	With "All" up/dn cmd, and store DMX cmd
Scenes Up fade times	Instant to 30 minutes	10 seconds	With Up>Dn time command
Scenes Down fade times	Instant to 30 minutes	10 seconds	Down starts after Delay completes
Scenes Delay times	Instant to 30 minutes	1 second	Delays Down fade after start of Up fade
SHOWS SETTINGS	Range	After Reset	Notes
Local Shows	On/Off	Off	If On, turns off Scenes
Remote Shows	On/Off	Off	If On, turns off Scenes
Show types	Show or Chase	Chase	Show stops at End scene, Chase re-starts
Show xfade types	Proportional/slope		Time Proportional fade (best for Shows)
Chase xfade types	Proportional/slope	Slope	Constant Slope fade (best for Chases)
Chase direction	Forward, auto reverse	Forward	Chase may be set to be auto reversing
Show/Chase number range	1 to 20	Chase/Slope 1	
Show/Chase labels	8 alpha-numeric digits	Title 1-64	Includes U/case, L/case, and symbols
Show/Chase Start scene	Scene 1-63	1	Show/Chases are min 2 scenes long
Show/Chase End scene	(Start Scn +1) to 64	64	Show/Chases are min 2 scenes long
Cue/step wait times	Stop, 0.1 sec to 30 mins	10 seconds	"Wait" is time between cue steps

DIMMER INSTALLATION

The Nebula like all SCR dimmer packs is an inherent generator of EMI (electro-magnetic Interference) and requires careful installation following good wiring and earthing practice. The potential for power problems with a dimmer installation increases with the number of dimmers. Involving professional assistance with proven experience is highly recommended, as correcting problems later can be very expensive. The following points should be considered in order to achieve reliable operation, and to ensure minimum interference to other equipment such as audio and video equipment in Theatres and TV Studios:

SUPPLY TRANSFORMER

1. **Locate the dimmers and the supply transformer as close together as possible.**
2. **Ensure the transformer is of the correct type and rating for the non-linear load of the dimmers you are installing.**
3. **On larger installations consider using a dedicated transformer for the dimmer installation.**

DIMMER SUPPLY CABLING

1. **Keep the supply cabling between the transformer, switchboard and dimmers as short as possible.**
2. **Minimum inductance in the supply cabling is critical. Keep all phase and neutral cables tightly bunched together. On smaller installations use of neutral screen or composite cables is recommended. On larger installations ensure that all phase cables are bound close to the neutral cable(s). Avoid solid buss-bar riser systems.**
3. **Use of a neutral conductor that is at least 1.5 times the area of any phase conductor is recommended. This becomes more important in larger installations.**

DIMMER LOAD CABLING

1. **Install the dimmers as close to the lighting loads as possible.**
2. **Do not use common neutrals. Each dimmer must have its own phase and neutral conductor, preferably a twisted pair.**
3. **The phase and neutral for each dimmer must be grouped together or be adjacent cores in a composite cable.**
4. **Dimmer load cables are a source of EMI interference. Keep dimmer load cables clear of all other power and data cables. Run dimmer cables in earthed metal conduit or trunking if EMI interference may be an issue.**
5. **Ensure all equipment and exposed metal is correctly earthed.**

DMX-512 INSTALLATION

As the DMX512 communication system has no built error checking, the DMX512 wiring installation must follow proper practice to achieve reliable operation. The following points (but not limited to) need to be considered for any DMX512 installation.

1. **Always use a good quality shielded twisted pair cable suitable for the DMX512/RS485 communications standard ANSI E1.11-2004.**
2. **Although a DMX512 data link only requires one twisted pair plus the shield, it is recommended that DMX512 cables be two twisted pairs and shield and that all five pins of the XLR connector be wired.**
3. **Ensure the correct 5 pin XLR connectors are used and that they are wired correctly.**
4. **Never allow the shield to be connected to earth, XLR metal body or any other metal object except when done by a manufacturer within a DMX512 device.**
5. **Never disconnect the shield at one or both ends of a DMX512 cable.**
6. **DMX512 wiring must be a daisy chain, starting at the control console and looping from device to device. The signal must not have any splits or T connections, except when using an electronic splitter.**
7. **The last device in the line should be terminated with a 120 ohm resistor.**
8. **In permanent installations keep DMX512 cabling at least 600mm away from power and dimmer load cables.**
9. **Preferably run the DMX512 cabling in earthed metal conduit or trunking.**
10. **Whilst the DMX512/RS485 standard allows for up to 32 devices on a line, keep the number well below this to ensure reliability.**
11. **The use of electronic DMX512 splitters is recommended. These allow the signal to split into several legs, making cabling simpler and ensuring that failure of one device or cable does not fail the whole system.**

DMX512 splitters re-shape and buffer the received DMX. Isolated splitters also help to prevent issues caused by earth loops and heavy loading. Electronic splitters may be cascaded. Theatrelight DMX Splitters are available as an 8 channel 19 inch, 1 U rack mounting configuration, or as a 4 channel stand-alone portable version

NEBULA DIMMER OPERATION

The examples below assume a start from the top menu level—pressing the Back key several times always goes to top menu: the screen shows “**Theatrelight NZ**”, together with the model, number of channels, the software version, and the current DMX Start number. If the keys are locked, the LCD will show “Keys Locked”.

UNLOCKING THE KEYS

The keys may be unlocked as follows:

1. **To unlock the keypad, hold ◀ + ▶ + ▼ until the message “Keys Locked” disappears (about 8 seconds).**
2. **Release all keys: the screen shows “Changes saved to flash memory”.**

LOCKING THE KEYS

After changing any settings, you can disable the keys to prevent unauthorised changes as follows.

1. **Press the Back key several times to reach the top menu. This also saves the latest changes.**
2. **To lock the keypad, hold ◀ + ▶ + ▲ until the message “Keys Locked” appears (about 2 seconds).**
3. **Release all keys: the screen shows “Changes saved to flash memory”.**

SETTING DMX START OR PATCH MODE

The current DMX mode (Start Mode or Patch Mode) is shown on the top menu. To set DMX Start Mode :

1. **From the top menu, press Menu twice.**
2. **Press Up ▲ or Down ▼ to select Start or Patch mode, then press “on” (Right ▶) to set the mode On.**

SETTING DMX START OR PATCH ADDRESSES

To change the DMX address/s:

1. **While in the menu above press “setup” (Menu).**
2. **In Start Mode, press Up ▲ or Down ▼ to adjust the DMX address, Left ◀ or Right ▶ to adjust tens/hundreds.**
3. **In Patch Mode, press Up ▲ or Down ▼ to adjust the DMX address, Left ◀ or Right ▶ to change dimmers.**

SETTING DMX FAIL MODE

To set the DMX Fail Mode to either “Fade to Black” or “Hold DMX levels” :

1. **While In the DMX Start Address Menu above, press “fail” (Menu).**
2. **Press Up ▲ or Down ▼ to select the mode, then press “on” (Right ▶) to set the mode On.**

SETTING DMX FAIL MODE TIMES

To set the DMX Fail Mode times:

1. While In the Fail Mode Menu above, press “*times*” (Menu).
2. Press Left ◀ or Right ▶ to select the Delay or Fade times, then press Up ▲ or Down ▼ to set the time.
3. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

SETTING DMX FAIL SCENE

To set the DMX Fail Scene number:

4. While In the Fail Mode Menu above, press “*times*” (Menu).
5. Press Left ◀ or Right ▶ to select “Fade to Scene”, then press Up ▲ or Down ▼ to set the scene.
6. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

SETTING DIMMER TEST/SET LEVELS

Test/Set levels take over control from any input DMX or other control level. To set Test/Set levels for each dimmer:

1. From the top menu, press Menu twice, select “Dimmer Settings”, press Menu.
2. Select “Test/set dimmers”, press Menu.
3. Press Left ◀ or Right ▶ to select the dimmer, Up ▲ or Down ▼ to adjust the level.
4. Press “All” (Left key) with Up ▲ or Down ▼ to adjust all test levels.
5. Press “Flash” (Menu key) to flash the dimmer if required to identify the channel.
6. Press “All” (Left key) with “Flash” (Menu key) to flash all dimmers.
7. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

SETTING DIMMER MINIMUM LEVELS

To set Minimum levels for each dimmer:

1. From the top menu, press Menu twice, select “Dimmer Settings”, press Menu.
2. Select “Min levels setup”, press Menu.
3. Press Left ◀ or Right ▶ to select the dimmer, Up ▲ or Down ▼ to adjust the level.
4. Press “All” (Left key) with Up ▲ or Down ▼ to adjust all levels.
5. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

SETTING DIMMER MAXIMUM LEVELS

To set Maximum levels for each dimmer:

1. From the top menu, press Menu twice, select “Dimmer Settings”, press Menu.
1. Select “Max levels setup”, press Menu.
2. Press Left ◀ or Right ▶ to select the dimmer, Up ▲ or Down ▼ to adjust the level.
3. Press “All” (Left key) with Up ▲ or Down ▼ to adjust all levels.
4. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

SETTING NON-DIM LEVELS

To set Non-Dim levels for each dimmer:

1. From the top menu, press Menu twice, select “Dimmer Settings”, press Menu.
2. Select “Non-Dim levels” (on page 2), press Menu.
3. Press Left ◀ or Right ▶ to select the dimmer, Up ▲ or Down ▼ to set the level.
4. Press “All” (Left key) with Up ▲ or Down ▼ to adjust all dimmers.
5. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

SETTING OFF LEVELS

To set Off levels for each dimmer:

1. In Menu Level 0, press Menu twice, select “Dimmer Settings”, press Menu.
2. Select “Off levels” (on page 2), press Menu.
3. Press Left ◀ or Right ▶ to select the dimmer, Up ▲ or Down ▼ to set the level.
4. Press “All” (Left key) with Up ▲ or Down ▼ to adjust all dimmers.
5. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

SETTING DIMMER CURVES

To set the Dimmer Curve for each dimmer:

1. From the top menu, press Menu twice, select “Dimmer Settings”, press Menu.
2. Select “Dimmer curve setup” (on page 2), press Menu.
3. Press Left ◀ or Right ▶ to select the dimmer, Up ▲ or Down ▼ to set the curve.
4. Press “All” (Left key) with Up ▲ or Down ▼ to adjust all curves.
5. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

Dimmer curves available are In = Incandescent, ND = Non-Dim, TV =Television/Film colour temp control, FI, Ne = Fluorescent, Neon discharge tubes, LP = Linear Power, LA = Linear Phase Angle.

SETTING PROPORTIONAL LEVELS

To set Proportional levels for each dimmer:

1. From the top menu, press Menu twice, select “Dimmer Settings”, press Menu.
2. Select “Off levels” (on page 3), press Menu.
3. Press Left ◀ or Right ▶ to select the dimmer, Up ▲ or Down ▼ to set the level.
4. Press “All” (Left key) with Up ▲ or Down ▼ to adjust all dimmers.
5. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

SETTING SOFT-START TIMES

To set Soft-start times for each dimmer:

1. From the top menu, press Menu twice, select “Dimmer Settings”, press Menu.
2. Select “Soft-start setup” (on page 3), press Menu.
3. Press Left ◀ or Right ▶ to select the dimmer, Up ▲ or Down ▼ to adjust the time.
4. Press “All” (Left key) with Up ▲ or Down ▼ to adjust all times.
5. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

RESETTING DMX AND DIMMER PARAMETERS

To reset all DMX and dimmer parameters:

1. From the top menu, press Menu twice, select “Dimmer Settings”, press Menu.
2. Select “Reset commands” (on page 3).
3. Press Menu, then select the required reset mode using Up ▲ or Down ▼ .
4. Press Menu: the screen asks for confirmation: press “OK” (the Menu key).
5. The screen shows “Resetting all Dimmer and DMX parameters”, then restarts the dimmer pack.

DISPLAYING INPUT DMX LEVELS

To display the input DMX levels for each dimmer:

1. From the top menu, press Menu once, select “Input DMX levels”, press Menu.

2. The display will remain set, and restore after power up.
3. Or else press **Back** to reach the top menu.

DISPLAYING FINAL DIMMER LEVELS

To display the final dimmer levels for each dimmer:

1. From the top menu, press **Menu** once, select “**Final Dimmer levels**”, press **Menu**.
2. The display will remain set, and restore after power up.
3. Or else press **Back** to reach the top menu.

DISPLAYING TEMPERATURE HISTORY

To display the temperature history for the dimmer pack:

1. From the top menu, press **Menu** once, select “**Temperature History**” (page 2), press **Menu**.
2. The display will remain set, and restore after power up.
3. Or else press **Back** to reach the top menu.

DISPLAYING VOLTAGE AND FREQUENCY

To display the voltage and frequency of phases A, B, and C:

1. From the top menu, press **Menu** once, select “**Voltage and Frequency**” (page 2), press **Menu**.
2. The display will remain set, and restore after power up.
3. Or else press **Back** to reach the top menu.

CALIBRATING VOLTAGE

To calibrate the voltage readout of phases A, B, and C:

1. While in the “**Voltage and Frequency**” menu above, press “**cal**” (**Menu**).
2. Press **Left** ◀ or **Right** ▶ to select the phase, **Up** ▲ or **Down** ▼ to adjust the voltage display.
3. To save the new calibration values immediately press **Back** until you reach the top menu: the screen shows “**Changes saved to flash memory**”.

DISPLAYING FAN STATUS

To display the fan status/test screen:

1. From the top menu, press **Menu** once, select “**Fan Status**” (page 2), press **Menu**.
2. The display will remain set, and restore after power up.

3. Or else press Back to reach the top menu.

TESTING THE FAN

To test the fan at full speed:

1. While in the Fan Status Menu above, press “test” (Menu).
2. The fan goes to full speed as long as the key is pressed
3. The display will remain set, and restore after power up.
4. Or else press Back to reach the top menu.

DISPLAYING SCENES PLAYBACK LEVELS

To display playback levels from Scenes, Shows and Chases:

1. From the top menu, press Menu once, select “Scenes P/B Levels” (page 3), press Menu.
2. The display will remain set, and restore after power up.
3. Or else press Back to reach the top menu.

DISPLAYING REMOTE CONTROL DATA

To display the first 21 hexadecimal values received or transmitted on the RS-485 data line:

1. From the top menu, press Menu once, select “Remote RX Data” or “Remote TX Data” (page 3), press Menu.
 2. The display will remain set, and restore after power up.
 3. Or else press Back to reach the top menu.
- Note that any changes made to Nebula parameters, or the current menu level will be saved automatically 10 minutes after the last key press.

NEBULA STAGE SCENES OPERATION

Every Nebula fitted with Stage Scenes software has 64 Scenes (each of 3, 6 or 12 dimmer levels according to model). Each scene has the following attributes:

- An up fade time from Instant to 30 minutes
- A down fade time from Instant to 30 minutes
- A fade down delay time from Instant to 30 minutes
- A wait time of Instant to 30 minutes for use with automatic Shows
- An editable scene label of 8 alpha-numeric characters
- Local setting of each dimmer level in each scene, including local record from DMX levels, or sourced from a previously copied Scene
- Instant remote record of Blackout or Full levels, or mixed DMX and Scene levels
- Each Nebula may be set to respond to one area out a maximum of 8 area commands
- Dipless crossfade to any scene from 1 to 64 from local pushbutton, or remote matching area command
- Each Nebula may be given a Report Identification number from 1 to 250 for use with Theatrelight Reporting software
- Continuous readout of live Scene levels
- Continuous readout of transmitted and received remote control data commands

The examples below assume a start from the top menu level—pressing the Back key several times always goes to top menu: the screen shows “**Theatrelight NZ**”, together with the model, number of channels, the software version, and the current DMX Start number.

SETTING LOCAL SCENES ON/OFF

To set the local Scenes playback on or off:

1. From the top menu, press Menu twice.
2. Press Up▲ or Down▼ to select “Local Scenes” (on page 2), then press “on” (Right ▶) or “off” (Left ◀) to set the scenes playback On or Off (this also sets off Local and Remote Shows).
3. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

SETTING REMOTE SCENES ON/OFF

To set Remote Scenes playback on or off (for use with Theatrelight Wallplate controllers):

1. From the top menu, press Menu twice.
2. Press Up▲ or Down▼ to select “Remote Scenes” (on page 2), then press “on” (Right ▶) or “off” (Left ◀) to enable or disable Remote Scenes playback (this also sets off Local and Remote Shows). The Remote LED lights when Remote Scenes are enabled.
3. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

SETTING UP AREA ID AND REPORT ID

To set Remote Scenes area ID (for use with other Nebulas and with Theatrelight Wallplate controllers), and Report ID (for use with Theatrelight Reporting software) for each dimmer pack:

1. From the top menu, press Menu twice.
2. Press Up▲ or Down▼ to select “Setup Area ID” (on page 2), press Menu.
3. With the cursor over the Area ID, press ▲ or Down▼ to set the Area ID to a value between 1 and 8.
4. Press Right ▶ or Left ◀ so the cursor is over the Report ID number.
5. With the cursor over the Report ID, press ▲ or Down▼ to set the Report ID to a value between 1 and 250.
6. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

SETTING SCENES LEVELS

To setup Scenes levels:

1. From the top menu, press Menu twice.
2. Press Up▲ or Down▼ to select “Local Scenes” (on page 2), then press Menu.
3. Press Up▲ or Down▼ to select the Scene number you want to edit, then press Menu.
4. Press Left ◀ or Right ▶ to select the dimmer, Up▲ or Down▼ to adjust the Scene level.

5. Hold Left ◀, then press Right ▶ (“0 ▶ F”) to toggle the level On or Off.
6. Press “All” (Left key) with Up ▲ or Down ▼ to adjust all levels of the scene.
7. With the cursor over “dmx” press Up ▲ to load current DMX values to the Scene (the “dmx” letters change to “DMX” while this is enabled).
8. Press Down ▼ or Left ◀ or Right ▶ to cancel DMX levels.
9. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

SETTING SCENES LABELS

Each Scene may be given an 8 letter name or label to help identify its function. To set the Scene label:

1. Go to the Scenes Edit menu (see step 3 above).
2. Press Left ◀ while the cursor is over the Dimmer 1 level—the cursor jumps to the start of the Scene label.
3. Press Up ▲ or Down ▼ to select the alpha numeric-character from the list below.
4. Press Left ◀ or Right ▶ to select the text position for the character.
5. While in text edit mode the function of the Back key changes to Upper/Lower case: press the Back key to swap the letter from lower to upper case.
6. To complete the label (and re-enable the Back function), press Right ▶ until the cursor is over the Dimmer 1 level.
7. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

The order of the alpha-numeric characters is as follows.

<<<<<< Up ▲ key action Down ▼ key action >>>>>>

Upper case characters: (Space)ABCDEFGHIJKLMN OPQRSTUVWXYZ! " # \$ % & ' () * + , - . /

Lower case characters: (Space)abcdefghijklmnopqr stuvwxyz0123456789 : ; < = >

Note that lower case is the default case. A space can always be found easily at the top of the list—hold Up ▲ for 1 or 2 seconds until the space appears (this also resets to lower case).

SETTING SCENES FADE TIMES

To setup Scenes fade-times (and also the Wait times between Show Cues):

1. From the top menu, press Menu twice.
2. Press Up ▲ or Down ▼ to select “Local Scenes” (on page 2), then press Menu.

3. Press Up ▲ or Down ▼ to select the Scene number you want to edit, then press Menu.
4. Press “times” (Menu).
5. Press Left ◀ or Right ▶ to select Up, Down, Delay, or Wait time (the time delay between Show/Chase cues) then press Up ▲ or Down ▼ to set the time.

Up, Down, and Delay times can be set from Instant to 30 minutes. Show Cue Wait time can be set from 0.1 second to 30 minutes, or at Stop to inhibit cue advance.

6. Press “All” (Left key) with Up ▲ or Down ▼ to adjust the times of all Scenes.
7. Press “Up>Dn” (Menu) to set the Scene Down fade time the same as the Up fade time.
8. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

PLAYING BACK SCENES

To playback local Scene levels at their fade-times:

1. From the top menu, press Menu twice.
2. Press Up ▲ or Down ▼ to select “Local Scenes” (on page 2), then press Menu.
3. Press Up ▲ or Down ▼ to select the Scene number you want to playback, then press “Go” (Right ▶).

The new scene is faded in at its fade-times—the progress of the fade is displayed in the LCD. If the Remote LED is lit, the Nebula issues a “Go to Scene/Area” command on the data network to other matching area Nebulas (indicated by the Remote LED flashing). Scenes will not play back if Local Scenes is set Off.

4. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.
- The new scene number (and its fade state if fading) is also displayed on the top level menu page.

COPYING AND PASTING SCENES

All levels, labels, and fade times of a scene may be copied to another scene as follows:

1. From the top menu, press Menu twice.
2. Press Up ▲ or Down ▼ to select “Local Scenes” (on page 2), then press Menu.
3. Press Up ▲ or Down ▼ to select the Scene number you want to copy, then press “copy” (Left ◀).

The display flashes “paste”, together with the scene number of the copied scene.

4. Press Up ▲ or Down ▼ to select the Scene number you want to paste into, then press “paste” (Left ◀).
5. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

NEBULA STAGE SHOWS OPERATION

Every Nebula fitted with Stage Scenes software has an auto Show facility which uses the 64 scenes as cue states of an auto-sequencing Show or Chase. A Show runs through its cues until the End scene when it stops, whereas a Chase does an auto-restart on reaching the End scene.

The Nebula can record a total of 20 Shows or Chases, each with programmable start and end scenes selected from the 64 recorded scenes with their fade times and levels. The wait time programmed on each scene is the time delay before the next scene is cross-faded in. Each Show or Chase has the following attributes:

- Programmable start scene
- Programmable end scene
- Wait times between cues from 0.1 second to 30 minutes. Wait time may also be set at stop for slaved Nebulas.
- An editable Show label of 8 alphanumeric characters
- Each of the 20 Shows may be programmed as a Show (an auto-sequence of scenes finishing at the last scene) or as a Chase (an auto-sequence of scenes which restarts after the last scene)
- Chases can be programmed to be auto-reversing
- Shows and Chases can be programmed to use time-proportional or constant slope cross-fades
- Remote cue go, cue back, start, end, and play/pause control from matching area Wallplate show controllers.

The examples below assume a start from the top menu level—pressing the Back key several times always goes to top menu: the screen shows “**Theatreight NZ**”, together with the model, number of channels, the software version, and the current DMX Start number.

SETTING LOCAL SHOWS ON/OFF

To set the local Shows playback on or off:

1. From the top menu, press Menu twice.
2. Press Up▲ or Down▼ to select “Local Shows” (on page 3), then press “on” (Right ▶) or “off” (Left ◀) to set the shows playback On or Off (this also sets off Local and Remote Scenes).
3. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

SETTING REMOTE SHOWS ON/OFF

To set Remote Shows playback on or off (for use with other Nebulas and Theatrelight Wallplate controllers):

1. From the top menu, press Menu twice.
2. Press Up▲ or Down▼ to select “Remote Shows” (on page 3), then press “on” (Right ▶) or “off” (Left ◀) to enable or disable Remote Shows playback (this also sets off Local and Remote Scenes). The Remote LED lights when Remote Shows are enabled.
3. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

SETTING UP AREA ID AND REPORT ID

Remote Shows uses the same Area ID and Report ID as for Scenes mode. If you need to change these numbers:

1. From the top menu, press Menu twice.
2. Press Up▲ or Down▼ to select “Setup Area ID” (on page 2), press Menu.
3. With the cursor over the Area ID number, press ▲ or Down▼ to set the Area ID to a value between 1 and 8.
4. Press Right ▶ or Left ◀ so the cursor is over the Report ID number.
5. With the cursor the Report ID number, press ▲ or Down▼ to set the Report ID to a value between 1 and 250.
6. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

PLAYING BACK OR PAUSING THE CURRENT SHOW

To start, or play/pause the current Show:

1. From the top menu, press Menu twice.
2. Press Up▲ or Down▼ to select “Local Shows” (on page 3), then press Menu. The screen shows the current show or chase type, the number, its title, the current cue number, and wait completion state.
3. Press Up ▲ to reset the Show or Chase to Cue 1 (the Start Scene). This action fades in the first cue, with cue stepping paused.

If the Remote LED is lit, the Nebula issues a “Start Show/Area” command on the data network to other matching area Nebulas (indicated by the Remote LED flashing).

4. **Press Down ▼ to Play the Show—the show starts stepping through its cues.**
5. **Press Down ▼ to Pause the Show—cue stepping is inhibited, but fades are allowed to complete.**

If the Remote LED is lit, the Nebula issues a “Play (or Pause) Current Show/Area” command on the data network to other matching area Nebulas (indicated by the Remote LED flashing). Also (if the wait time for the scene is not set at “stop”) at the end of the wait time, the Nebula issues a “Go to Show Scene/Area” command on the data network to other matching area Nebulas (indicated by a single flash of the Remote LED).

6. **Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.**

CHANGING THE CURRENT SHOW NUMBER

To change the current Show number:

1. **From the top menu, press Menu twice.**
2. **Press Up ▲ or Down ▼ to select “Local Shows” (on page 3), then press Menu.**
3. **Press Left ◀ twice to bring the cursor over the current Show number, then press Up ▲ or Down ▼ to select the new show number.**

Local Show playback is set to the Cue 1 of the new show at Pause, and if the Remote LED is lit, the Nebula issues a “Start Show/Area” command on the data network to other matching area Nebulas (indicated by the Remote LED flashing).

4. **Press Right ▶ twice to bring the cursor over Start/Play: press Down ▼ to play the Show or Chase.**

If the Remote LED is lit, the Nebula issues a “Play Current Show/Area” command on the data network to other matching area Nebulas (indicated by the Remote LED flashing).

5. **Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.**

The new Show number and title, the current cue and label, and the wait completion state are also displayed on the top level menu page.

CHANGING THE CURRENT SHOW CUE

To change the current Show cue number:

1. **From the top menu, press Menu twice.**
2. **Press Up ▲ or Down ▼ to select “Local Shows” (on page 3), then press Menu.**
3. **Press Left ◀ once to bring the cursor over the current Show Cue, then press Up ▲ or Down ▼ to select the new cue number, then press “Go” (the Back key).**

The new cue is faded in at the fade-times for that scene, and the show is set to “Play”. If the Remote LED is lit, the Nebula issues a “Go to Show Scene/Area” command on the data network to other matching area Nebulas (indicated by the Remote LED flashing). Cue 1 is always the Start Scene of the Show or Chase.

4. **Press Right ▶ or Left ◀ so the “back” label appears under the Back key.**
5. **Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.**
The new cue and its label, and the wait completion state are also displayed on the top level menu page.

EDITING THE CURRENT SHOW CUE

To edit levels, labels, and fade times of the current Show cue:

1. **From the top menu, press Menu twice.**
2. **Press Up ▲ or Down ▼ to select “Local Shows” (on page 3), then press Menu.**
3. **Press Left ◀ once to bring the cursor over the current Show Cue: “edit” flashes over the Menu key.**
4. **Press Menu. The display now shows the Scene Levels Menu described earlier under “Setting Scenes Levels”.**
From this menu you can edit Scenes levels, fade times, and wait times as described earlier under “Setting Scene Levels” and subsequent instructions.
5. **After editing the Scene, press Back to return to the Cue Go menu: press “Go” (the Back key) to fade to the newly edited Scene.**

The new cue is faded in at the new fade-times for that scene and the show is set to “Play”. If the Remote LED is lit, the Nebula issues a “Go to Show Scene/Area” command on the data network to other matching area Nebulas (indicated by the Remote LED flashing).

6. **Press Right ▶ or Left ◀ so the “back” label appears under the Back key.**
7. **Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.**
The new cue and its label, and the wait completion state are also displayed on the top level menu page

SETTING SHOW START AND END SCENES

To change a Show Start or End Scene:

1. **From the top menu, press Menu twice.**
2. **Press Up ▲ or Down ▼ to select “Local Shows” (on page 3), then press Menu.**
3. **Press Left ◀ twice to bring the cursor over the current Show number, then press Up ▲ or Down ▼ to select the show you wish to edit (“edit” flashes above the Menu key).**
4. **Press Menu. The cursor flashes over the Start Scene number of the Show or Chase.**

5. Press Up ▲ or Down ▼ to select the Start Scene number for the Show.
6. Press Right ► to bring the cursor over the End Scene number.
7. Press Up ▲ or Down ▼ to select the End Scene number for the Show.
8. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”. Show and Chases have a minimum length of two Scenes.

SETTING SHOW TITLES

Each Show or Chase may be given an 8 letter title to help identify its function. To set the Show title:

1. Go to the Show Edit menu in step 4 above (“Setting Show and End Scenes”).
2. Press Left ◀ while the cursor is over the Start Scene number—the cursor jumps to the start of the Show title.
3. Press Up ▲ or Down ▼ to select the alpha numeric-character from the list below.
4. Press Left ◀ or Right ► to select the text position for the character.
5. While in text edit mode the function of the Back key changes to Upper/Lower case: press the Back key to swap the letter from lower to upper case.
6. To complete the label (and re-enable the Back function), press Right ► until the cursor is over the Start Scene number.
7. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

The order of the alpha-numeric characters is as follows.

<<<<<< Up ▲ key action Down ▼ key action >>>>>>

Upper case characters: (Space)ABCDEFGHIJKLMN OPQRSTUVWXYZ! "#\$%&'()*+,-./

Lower case characters: (Space)abcdefghijklmnopqr stuvwxyz0123456789:;<=>

Note that lower case is the default case. A space can always be found easily at the top of the list—hold Up ▲ for 1 or 2 seconds until the space appears (this also resets to lower case).

SETTING SHOW OR CHASE TYPE

The Nebula can play two sequence types: a Show or a Chase. A Show runs through its cues until the End scene when it stops, whereas a Chase does an auto-restart on reaching the End scene. Both Shows and Chases may be set to use Time Proportional or Constant Slope fades, while Chases may also be set to be auto-reversing. To set the Show/Chase type:

1. Go to the Show Edit menu in step 4 above (Setting Show and End Scenes).

2. Press Left ◀ while the cursor is over the Start Scene number: the cursor jumps to the start of the Show title.
3. The Menu key flashes “show/chs” —press the Menu key to cycle the Show/Chase through the types from the list below.
4. To exit the Show/Chase type menu (and Show title menu), press Right ▶ until the cursor is over the Start Scene number.
5. Press Back until you reach the top menu: the screen shows “Changes saved to flash memory”.

The Show/Chase type selections are:

Ch/slp	Chase, constant slope fade. (This is the default type set after resetting the flash memory)
Ch/fad	Chase, time proportional fade
Ch/slp ◀	Chase, constant slope fade, auto-reversing
Ch/fad ◀	Chase, time proportional fade, auto-reversing
Sh/slp	Show, constant slope fade
Sh/fad	Show, time proportional fade

“Time proportional crossfade” means that a dimmer programmed to fade from say 40 to 60 percent finishes its fade at exactly the same time as a dimmer moving from 0 to 100%.

“Constant slope crossfade” means that all dimmers fade at the same rate: a dimmer programmed to fade from 50% to Off percent reaches zero at the same as a dimmer moving from 100% to Off reaches 50%. The constant slope fade is preferable in “comet” chases, or in any sequence of lighting changes where the cues overlap.

REMOTE SCENE AND SHOW CONTROL

Nebulas (and Meteors and Quasars) fitted with Stage Scenes software can be connected together (and to Theatrelight Wallplates) using TLNet, a highly reliable, slow speed RS-485 data standard.

COMMUNICATION

The communication system works at 9600 baud to RS485 standard. This slow speed method is chosen to provide the maximum in reliability and noise resistance over the very long runs of cable used in large buildings and industrial environments. In addition, the data packet is kept as short as short as possible to minimise the possibility of collision.

RS-485 TRANSCEIVER

Nebula dimmers and Theatrelight Wallplates use a special half-duplex RS-485 transceiver rated at one tenth normal RS-485 unit load. This means over 400 Nebula dimmer packs and/or Wallplates can be connected to the same data line before loading degrades the driver signal significantly. The transceiver chips also have a high common mode range, a very high input impedance, and low power consumption. The chip also features a high internal ESD (ElectroStatic Discharge) tolerance, which is further enhanced by additional surge arrestors external to the chip. As a guideline, the cable run should be limited to 2 kilometres, and the total number of Nebulas and Wallplates on a single data line to 200 without using data buffers. In any event, at the completion of all larger installations, the data line should always be inspected with an oscilloscope to confirm that the data signal has good edges and is free of noise and reflections.

POWER SUPPLY

A 12 volt supply is carried over the Cat 5 data cable to supply remote Wallplates where used. Each Nebula has a 12 volt, 200 mill-amp constant current source, allowing every Nebula to drive up to 100 Wallplates. Normal Wallplate power requirements is 12 volts, with a total load of just 1.5ma per Wallplate (one LED on). Each Wallplate has its own regulator, allowing reliable operation at supply levels down to 6 volts.

CONNECTION AND WIRING

Nebula dimmer packs and Theatrelight Wallplates are designed to be connected together using CAT 5 cable, the standard cable used for Ethernet wiring. Every Nebula and Wallplate is fitted with an RJ45 socket, allowing the use of a standard Ethernet crimping tool for fitting an RJ45 plug to the CAT 5 cable. The wiring of the cable to the RJ45 sockets is also exactly as used for an Ethernet installation. Nebula dimmers and Wallplates must be wired in a continuous daisy chain, starting at the dimmer rack, and looping from device to device. The data line must not have any splits, and should preferably be continuous with the fewest possible joins in the line. Short "T" connections of 300mm may be used to connect to each Nebula or Wallplate. Longer "T" connections should be avoided as they contribute reflections and noise. Keep the data cable at least 600mm away from power and dimmer load cables, preferably in an earthed metal conduit or trunking.

For convenience in initial installation and testing, each Nebula and Wallplate is also fitted with a loop-through RJ45 connector. However the loop-through method of wiring should not be used on any permanent installation as every connection contributes a possible failure point. The most reliable method of connection is to tap a short break-out of length say 300 mm onto the data cable *without cutting or nicking the main data cable*. As CAT 5 cable is composed of solid rather than stranded conductors, the cable should be subjected to a as little flexing as possible during installation.

High quality RJ45 connectors should be used to ensure a secure connection for each Nebula or Wallplate onto the common data line. On long runs, the last devices at opposite ends of the data line must be terminated with a 120 ohm resistor to keep reflections and noise to a minimum.

THEATRELIGHT WALLPLATES

The Theatrelight Wallplate is a simple 6 key intelligent lighting controller for use with Theatrelight Dimmers such as Nebula, Meteor and Quasar. The Wallplate is designed to be mounted in a standard 86mm square back box. The Wallplate is available in white or black. It is fitted with 6 push buttons, each key backlit with a blue LED. Other colour LEDs can be supplied to customer specification. Key legend can be engraved and paint filled, or laser etched to customer specification. Wallplates can also be silk-screened in wear resistant epoxy ink for larger order quantities.

WALLPLATE ELECTRONICS

Each Wallplate is run by an ultra low power microprocessor, which scans the keys and pre-set dipswitch settings, drives the LEDs, and transmits the appropriate commands to the data bus. The microprocessor also receives and interprets commands sent by other Wall plates or Nebulas such as scene, area, link, and master commands. All commands whether from its own keys or from remote Wallplates are stored in flash memory after a short time interval, so that at power-on, each Wallplate wakes up in the state it was in when it was turned off. For further details, and for help setting up a system with Nebula dimmers, refer to the Theatrelight Wallplate Instruction Manual on www.theatrelight.co.nz

REMOTE CONTROLLED SCENES

To link a number of Nebulas together for remote control of scenes over a large number of dimmers, each Nebula must be connected to the common data cable. Then each Nebula must be set up as follows

- 1. Each Nebula must be set with Local Scenes and Remote Scenes set On.**
- 2. Each Nebula must be set to an Area ID which matches the remote scene command, whether from other Nebulas, Theatrelight Wallplates, or remote computer.**
- 3. Each scene in each Nebula must be programmed for its correct playback levels and fade times.**

REMOTE CONTROLLED SHOWS

To link a number of Nebulas together for a synchronised show or chase over a large number of dimmers, each Nebula must be connected to the common data cable. Then each Nebula must be set up as follows

- 1. Each Nebula must be set with Local Shows and Remote Shows set On.**
- 2. Each Nebula must be set to an Area ID which matches the remote show command, whether from other Nebulas, Theatrelight Wallplates, or remote computer.**
- 3. Each Nebula must be set to the same current show, the same Show/Chase type, and with the same start and end scenes.**
- 4. Each Scene in each Nebula must be set to its correct levels and fade times.**
- 5. One Nebula only should be programmed with the correct wait times between cues- all others should have all scene wait times set to Stop. This ensures that only one Nebula can step its cues automatically, and issue the correct “Fade to Show Scene” commands to other area-matching Nebulas.**

MAINTENANCE

To keep your Nebula working well take note of these points:

- Keep the dimmer pack in a clean air environment: dust is detrimental to electronic insulation and fan life.
 - Ventilate dimmer cabinets and dimmer rooms adequately: heat is detrimental to electronic components.
 - Use a damp cloth to keep the dimmer pack clean. Do not use solvents, or solvent based pens.
 - Touring dimmer packs should travel in a sturdy road case with adequate protection from dust and vibration.
 - Use rear support plates on each dimmer pack when touring.
 - Take care that all power connections are firmly screwed down when operating the dimmer pack.
 - Ensure the dimmer packs are properly earthed to a low impedance earth system.
 - Use DMX splitters/reconditioners to ensure a clean DMX signal.
 - Terminate the last pack in the DMX line with a 120 ohm resistor for reliable operation.
-

Theatrelight contact address:

THEATRELIGHT LTD

PO BOX 13159

AUCKLAND, NEW ZEALAND

Phone 64-9-622-1187, 636-5805

Fax 64-9-636-5803

Web site: www.theatrelight.co.nz

E-mail: sales@theatrelight.co.nz

SPECIFICATIONS

CONSTRUCTION

Epoxy powder coat over zinc plated steel case. Legend silk-screened in solvent and abrasion resistant two pot epoxy ink.

FORM

3u high, 19 inch rack wide, with removable mounting wings. Rear support wings are available for touring cabinets

ELECTRONICS

Flash microprocessor with internal EEPROM for long life storage of all parameters. Digitally controlled SCR, IGBT or Sinewave dimming module fitted depending on model. The internal Switch Mode power supply is rated at 90 vac to 265 vac, 45 to 65 hertz, and uses long-life 105 degree rated capacitors.

LCD DISPLAY

4 line, 20 character display, STN Blue with auto-dimming super-bright white LED backlight.

PUSH BUTTONS

“Alps” brand computer keys with custom moulded keycaps.

MCBs

6KA rated MCBs provide full overload and short-circuit protection of power devices.

FILTERING

Iron powder toroidal chokes for linear current rise and minimum EMI. Theatrelight can provide filtering to customer standard on request.

COOLING

Long life low voltage speed controlled fan. Fan speed is proportional to temperature.

DMX CONNECTION

USITT DMX-512 1990 Digital multiplex system requiring twin twisted shielded cable approved for RS-422/485 of up to 600 metres. Dimmer refresh rate is every 22 milliseconds. Each Nebula presents 1/10th normal RS-485 unit load, allowing reliable DMX operation.

DMX SPLITTERS

DMX-512 splitters can be supplied by Theatrelight for larger installations. The splitter re-shapes and buffers the received DMX and drives a number of isolated floating DMX transmitters. Splitters may be cascaded. Theatrelight DMX Splitters are available in an 8 channel 19 inch, 1 U rack mounting configuration, or as a 4 channel stand-alone portable version.

POWER SUPPLY

Input: 90 to 265 volts AC, 1, 2 or 3 phase and Neutral, 45 to 65 Hz. Power consumption at no load is less than 5 watts.

EXTERNAL CONNECTIONS

Output: 12 channel, 6 and 3 channel versions. with SCR, IGBT or Sinewave modules.


Terminations: Moving cage terminals, or cable input with socket outputs depending on model and destination country. Socapex output versions available. Special socket versions may be made to customer order.

DMX Control Input: DMX-512 via gold plated 5 Pin XLR In/Thru connectors

RS-485 Control Input: via RJ 45 connectors mounted on the rear panel. A 12 volt 200ma supply is provided for powering wall plate controllers.

Diagnostic socket: Front panel socket for programming and diagnostic purposes (Theatrelight technicians use only).

DIMENSIONS



GLOSSARY OF THEATRE LIGHTING TERMS

ADD MODE	Mode in which pressing a channel Flash key adds the channel to the other lighting.
ANALOGUE	A smooth changing voltage (as opposed to digital)
BLACKOUT	All lights out on stage.
BLIND	Not showing on stage.
BO	Blackout; all lights out on stage.
BPM	Beats per minute: applied to music rhythms.
CHANNEL	One of the controlled output lines from a lighting desk; or a dimmer channel.
CHASE	A repetitive pattern of lighting changes.
CROSS-FADE	A smooth change from one lighting state to another.
CUE	An action or time event which results in new lighting on stage; the lighting state following the cue
DBO	Dead Black-out: no light on stage.
DIMMER	A power controller which changes the brilliance of lights connected to it.
DIPLESS	Applied to a cross-fade where a dimmer up at the same level on both the new and the old lighting states does not change level during the cross-fade.
DMX-512	A method of transmitting dimmer levels digitally over a two wire cable. (Digital MultipleX, 512 dimmers)
EEPROM	Electrically Erasable Programmable Read Only Memory: otherwise know as Flash Memory.
EMI	Electro-Magnetic Interference. Electrical noise.
ERASE	To clear and reset the memory.
FADER	A slider control.
FADE TIME	The time taken to complete a fade from full off to full on.
FLASH KEY	Any key which flashes a channel or scene to Full. Sometimes called Bump keys (USA).
GRAND MASTER	A master fader which controls the final output levels of a lighting desk.
HTP	Highest Takes Precedence: the highest command level is used as the controlling level

38 NEBULA OPERATION

KILL	Turn off a light.
KILL MODE	If Kill is on, pressing a Flash key turns off all other lighting. Sometimes called Solo or Swap mode.
LCD	Liquid Crystal Display
LED	Light Emitting Diode.
LEVEL	The brightness of a dimmer as a number from 0 (off), to 10 (full on), or from 0% to 100%.
LTP	Latest Takes Precedence: the latest command level is used as the controlling level
MASTER	A fader which has overall control of a number of levels or some other major function.
MCB	Miniature Circuit Breaker- a re-settable current protection device.
MIMIC DISPLAY	A display often using Light Emitting Diodes (LEDs).
NON-DIM	A dimmer set to Non-dim acts like a switch: on or off
PRESET	A row of faders representing all the channels in a scene; to set up faders in advance of a cue.
PREVIEW	To view a set of recorded levels without showing on stage.
SCENE	A recording which stores a single set of all channel levels.
SCENEMASTER	A master fader which controls the playback of a scene of recorded levels.
SCR	Silicon Controlled Rectifier. A unidirectional power switch used in dimmers
SEQUENCE	A repetitive pattern of lighting changes.
SHOW	A performance. In Theatrelight control panels, a Scenemaster which stores a sequence of cues.
SOFTSTART	A minimum fade up time programmed into a dimmer to enhance lamp life.
SOLO MODE	Another name for Kill mode.
SNAP FADE	An instant change from one lighting state to another.
STEP	To change from one scene or cue to another. Also, one scene of a Show or Chase.
TRIAC	A bi-directional power switch. Dimmers using triacs should be used with care on inductive loads.
USITT	United States Institute of Theatre Technicians. Arbiters of the DMX-512 standard.

INDEX

Area ID number.....	21	Maximum levels.....	16
Calibrating voltage.....	18	Minimum levels.....	15
Chase type.....	28	Non-dim levels.....	16
Chases editing.....	25	Off levels.....	16
Chases playback.....	25	Phase LEDs.....	3
Control connections.....	35	Playing scenes.....	23
Copying scenes.....	23	Proportional levels.....	17
Cue editing.....	26	Remote control.....	5, 30
Dimensions.....	36	Remote control data.....	19
Dimmer curves.....	16	Remote LED.....	3
Dimmer parameters.....	5, 6	Remote scenes.....	31
Dimmer settings.....	10	Remote scenes editing.....	21
DMX connections.....	35	Remote shows.....	32
DMX fail mode.....	4, 5, 10	Report ID number.....	21
DMX LED.....	3	Reset command.....	9, 17
DMX patch address.....	4, 14	RS-485 connections.....	35
DMX settings.....	10	Scene levels.....	19
DMX start address.....	4, 14	Scenes editing.....	21
End scenes.....	27	Show titles.....	28
Fan.....	4	Show type.....	28
Fan status.....	18	Shows editing.....	25
Fan testing.....	19	Shows playback.....	25
Features.....	1	Softstart fade times.....	7, 17
Final dimmer levels.....	18	Specifications.....	34
Front panel legend.....	2	Stage scene mode.....	20
Glossary.....	37	Start scenes.....	27
Input levels.....	17	Temperature history.....	18
Introduction.....	1	Temperature LED.....	3, 4
LCD display.....	3	Test levels.....	15
LEDs.....	3	Test/set levels.....	10
Locking keys.....	14	Unlocking keys.....	14
Maintenance.....	33	Voltage and frequency.....	18